

dareels






PRODUCT NAME/
SELMA - Outdoor sofa 2P
Structure only

ASSEMBLY INSTRUCTIONS


- ☐ Read all the explanations before assembling.
- ☐ Do not throw away the packing material before the assembling process is done.
- ☐ Assembly by two or more adults is recommended.

COMPONENTS AND PARTS LIST

Quantity



(A)	BACKREST		x 1
(B)	SEATER		x 1
(C)	MIDDLE LEG		x 1
(D)	LEG		x 2
(1)	BOLT		x 6
(2)	SPRING WASHER		x 6
(3)	FLAT WASHER		x 6
(4)	HEX WRENCH		x 1

Complete Assembly Picture



HOW TO ASSEMBLY

- 1 Place the seater (B) upside down and attach the middle leg (C)



- 2 Attach backrest (A) to seater (B) .



- ☐ When placing the body on the floor for the assembly, make sure that there is nothing on the floor. Spread out some papers (e.g. newspaper) for covering the floor to avoid scratches on the surface of the body.
- ☐ There is a possibility of accident and damage if you raise the product by the edge of the leg as center point, so please lift and then raise it up.
- ☐ When moving the product, please lift and move it without pulling.
- ☐ Because the product is quite heavy, please be careful when raising or moving the product

dareels

PRODUCT NAME/
SELMA - Outdoor sofa 2P
Structure only

ASSEMBLY INSTRUCTIONS

- ☐ Read all the explanations before assembling.
- ☐ Do not throw away the packing material before the assembling process is done.
- ☐ Assembly by two or more adults is recommended.

3 Attach leg (D) and bolt (1).

